



	Q7942AE HP 57 Series Photo Pack 10 x 15 cm, 60 sheets	Q7946EE HP 343 Series Photo Pack 10 x 15 cm, 60 sheets	Q7922EE HP 343 Series Photo Pack 13 x 15 cm, 60 sheets	Q7934EE HP 343 Series Photo Pack 10 x 15 cm, 100 sheets	Q7936AE HP 57 Series and 58 Series Photo Pack 10 x 15 cm, 100 sheets	Q7936EE HP 343 Series and 348 Series Photo Pack 10 x 15 cm, 100 sheets	Q7966EE HP 383 Series Photo Pack 10 x 15 cm, 150 sheets
HP Deskjet 450c/450cb/450wb	x						
HP Deskjet 460c/460cb/460wb		x	x	x			
HP Deskjet 5145/5150/5151/5550/5552/5650/5652/5655	x						
HP Deskjet 5740/5745		x	x	x	x		
HP Deskjet 5850	x				x		
HP Deskjet 5940		x	x	x	x		
HP Deskjet 6520/6540/6540d		x	x	x	x		
HP Deskjet 6620/6840/9800/9800d		x	x	x	x		
HP Deskjet 9650/9670/9680/9680g	x				x		
HP Deskjet 6940 Colour Inkjet Printer		x	x	x	x		
HP Deskjet 6980 Colour Inkjet Printer		x	x	x	x		
HP Digital Copier 410	x				x		
HP Officejet 4105/4110	x						
HP Officejet 4212/4215/4219/4252/4255	x				x		
HP Officejet 5505/5510/5515	x						
HP Officejet 6110	x				x		
HP Officejet 6205		x	x	x	x		
HP Officejet 6210/6215/7210/7310/7410		x	x	x	x		
HP PSC 1100/1200/1205/1210/1213/1215/1217/1219	x						
HP PSC 1310/1311/1312/1315/1315a/1317/1350/1340/1355	x				x		
HP PSC 1350	x						
HP PSC 1310/1510a/1600/1610		x	x	x			
HP PSC 2105/2108/2110/2115/2171/2175/2179/2210	x						
HP PSC 2350/2355/2355g		x	x	x	x		
HP PSC 2410/2510	x				x		
HP Photosmart 100/130/145/230/245	x						
HP Photosmart 325/335/375/385/422/428		x	x				
HP Photosmart 475		x	x	x			
HP Photosmart 2575/2610/2710		x	x	x	x		
HP Photosmart 3210/3110/3310							x
HP Photosmart 7150/7260/7345/7350/7450/7459/7550/7655	x				x		
HP Photosmart 7660/7755/7760/7762/7960/7960g	x				x		
HP Photosmart 8050		x	x	x	x		
HP Photosmart 8150/8450/8450g		x	x	x	x		
HP Photosmart 8250							x
HP Photosmart 8750/8750g		x	x	x	x		

